

**DANCOVER<sup>®</sup>**



Manual for  
**PRO FLOOR**



1

Your order will be delivered pre-assembled in flat sheets:

- 44 tiles per sheet
- 4 tiles wide by 11 deep
- Each sheet has a dimension of 915 x 1240mm.



2

For greater ease of use, it is normal to assemble your floor into rolls. First decide the dimensions you want the rolls (width and length). For example, if you leave the sheets at 4 tiles wide the width of each roll will be 1.24m.

Take each sheet and attach it to the next by pressing the tongues into the groove side. Continue assembling until the length of the roll has been obtained. It is good to know the number of m<sup>2</sup> in each roll for ease of calculating the number of rolls required to do a job. For example, if the roll width is 1.24m and you want 10m<sup>2</sup> per roll, make the roll length 8m.



3

When your roll size has been assembled flat, you then need to make it into a roll or cylinder.

Take the first few tiles and bend them at the hinges to make a triangle as demonstrated in the picture at left.



4

Use this triangle as the centre of the roll and keep it tight as you make the roll.



5

When the roll is complete, stand it on its end with the tongue side on top. Place a roll strap around the roll to keep it from coming undone.



6



You may now store your rolls vertically on the pallets on which they were delivered or horizontally in storage frames (stillages).



7

Your PRO-FLOOR® is now ready for storage, transport and on-site installation in its most efficient form.

8

On-site installation is very simple:



a) roll out the first roll straight making sure the groove side faces towards the direction of assembly.

b) roll out the next roll so the tongue sits loosely into the groove of the roll already placed on the ground.



c) press home the tongue into the groove and ensure the clips have engaged, this can be done with your feet, you will hear a distinct "click" on engagement.

d) continue until the area is completely covered.

9

When you have finished with your floor and wish to dismantle it, the procedure is even more simple;



Lift and separate the floor at the intersection of a roll width, the clips will disengage when rotated through 30-40°.

The floor is now separated longitudinally, you will need to also separate it at right angles back into the roll length of your choice.



Re-assemble the disassembled floor back into rolls.

## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

## National contact

### Denmark:

[denmark@dancover.com](mailto:denmark@dancover.com)

### UK:

[uk@dancover.com](mailto:uk@dancover.com)

### Germany:

[germany@dancover.com](mailto:germany@dancover.com)

### France:

[france@dancover.com](mailto:france@dancover.com)

### Sweden:

[sverige@dancover.com](mailto:sverige@dancover.com)

### Finland:

[suomi@dancover.com](mailto:suomi@dancover.com)

### Poland:

[polska@dancover.com](mailto:polska@dancover.com)

### Luxembourg:

[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

### Spain:

[espana@dancover.com](mailto:espana@dancover.com)

### Italy:

[italia@dancover.com](mailto:italia@dancover.com)

### Switzerland:

[schweiz@dancover.com](mailto:schweiz@dancover.com)

### Austria:

[austria@dancover.com](mailto:austria@dancover.com)

### Norway:

[norge@dancover.com](mailto:norge@dancover.com)

### Nederland:

[nederland@dancover.com](mailto:nederland@dancover.com)

### Ireland:

[ireland@dancover.com](mailto:ireland@dancover.com)

### Belgium:

[belgique@dancover.com](mailto:belgique@dancover.com)