

**DANCOVER<sup>®</sup>**



Manual

Fan

FGD-18

# High Velocity Floor Fan

Model: FGD-18

## Important Safety Instructions

Please keep this instruction manual in a safe place, along with the purchase receipt and carton for future reference. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not operate the appliance outdoors.
- Power plug must be removed from power socket before cleaning, servicing, maintenance or moving the appliance.
- The fan should be placed on a flat surface when operating to avoid overturning.
- The fan should not be operated in a damp place of high humidity (such as the bathroom).
- The fan is not designed to be outdoors.
- Improper installation may result in the risk of fire, electric shock and or injury to persons.
- The unit has no user-serviceable parts contained within. Do not attempt to repair, disassemble or modify the appliance.
- Do not insert foreign objects into the safety grill as this may cause damage to the appliance and/or user.
- Please ensure that the power supply the fan is intended to be plugged into matches the power rating on the rating label of the appliance.
- During assembly, the fan guard must be secured with the screw provided, and that before cleaning the fan must first be disconnected from the power outlet.
- Ensure that voltage indicated on the identification plate corresponds with the mains voltage.

# Assembly of your Pedestal Fan

## INSTRUCTIONS

- Remove the packaging material from the fan control box.
- Remove the screws from the two extremities of the base tube.
- Insert the tube into the fan body as shown in Figure 1.
- Align the screws hole and tighten the holding screws onto the base

NOTE: When installing the control box make sure the electrical wires are located on the outside of the base.





# Operation

1. Set your fan on a level dry surface.
2. Plug the power cord into 230V volt AC wall outlet.
3. The 3 speeds system is designed to give you maximum flexibility and to meet all your air circulation needs.
  - LOW or MED speed setting can be used for most of your requirements
  - High speed should only be necessary in exceptional circumstances
  - Select the desired speed by using the rotary control switch
  - Adjust to your desired air stream by tilting the fan assembly to the required position.

# Care and Cleaning Instructions

- Turn the control to OFF and unplug the fan before cleaning
- Use only a soft damp cloth to clean the fan
- Do not place the fan in water and never allow water to drip into the Motor Housing
- Do not use gasoline paint thinner or other chemicals to clean the fan
- To clean the fan Blade use 2 screwdrivers to disengage the hooks(8 hooks) holding the Front Grill to the Rear Grill(see Figure 2)
- Remove the Front grill
- Wipe the Blade and Grills
- Reassemble the fan by snapping the Front Grill into place
- Store the fan in its original box or cover the fan to protect it from dust
- Store it in a cool, dry place

## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

## National contact

Denmark: 70 26 76 20  
[denmark@dancover.com](mailto:denmark@dancover.com)

UK: 020 8099 7570  
[uk@dancover.com](mailto:uk@dancover.com)

Germany: 041 0266 7040  
[germany@dancover.com](mailto:germany@dancover.com)

France: 0975 181 800  
[france@dancover.com](mailto:france@dancover.com)

Sweden: 040 233 262  
[sverige@dancover.com](mailto:sverige@dancover.com)

Finland: 0 931 581 720  
[suomi@dancover.com](mailto:suomi@dancover.com)

Poland: 22 300 8602  
[polska@dancover.com](mailto:polska@dancover.com)

Luxembourg: +49 041 0266 7040  
[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

Portugal: 308 800 899  
[portugal@dancover.com](mailto:portugal@dancover.com)

Spain: 911 436 828  
[espana@dancover.com](mailto:espana@dancover.com)

Italy: 02 479 21 198  
[italia@dancover.com](mailto:italia@dancover.com)

Switzerland: 0840 000125  
[schweiz@dancover.com](mailto:schweiz@dancover.com)

Austria: 0662 626935  
[austria@dancover.com](mailto:austria@dancover.com)

Norway: 231 00 690  
[norge@dancover.com](mailto:norge@dancover.com)

Nederland: 0 858 880 524  
[nederland@dancover.com](mailto:nederland@dancover.com)

Ireland: 0 151 33 003  
[ireland@dancover.com](mailto:ireland@dancover.com)

Belgium: 0 28 08 08 09  
[belgique@dancover.com](mailto:belgique@dancover.com)