

**DANCOVER<sup>®</sup>**



Manual  
for  
Smoke machine

### Smoke (Fog) Machine, 400 Watt included Wired Remote Control

- Also read Safety Instructions before use !
- Ideal for Disco Parties
- Smoke Machine, 400Watt



### **WARNINGS:**



**HOT NOZZLE !**



**KEEP DISTANCE OF 50 CM**



**NEVER ADD FLAMMABLE SUBSTANCES**



**USE DEALER-RECOMMENDED FOG FLUID**

**Adequate ventilation:** The ventilation slots of the unit must never be covered. Make sure that there is a free space of at least 10cm to the side of and above the unit and that heat can be dissipated without obstruction.

**Cleaning:** Remove the plug-in power supply from the socket before cleaning the device. Clean the device with a dry cloth.

**Safety instructions:** • Do not allow the unit to overheat. Never place it near or over a radiator, fire place or other source of heat. • Do not plug the unit into a power source with wrong specific electrical outlet. If the system is not going to be used, unplug it from the power source. • This device is intended to be correctly oriented in a horizontal position.

**Caution:** To prevent electric shock, do not attempt to dismantle this product. Refer servicing to qualified service personnel.

- Indoor Use only !
- Metal Construction with Mounting Bracket
- Do not attempt to replace any parts of the product
- Keep unit away from rain and moisture (keep unit dry)
- Keep away from Children and Animals
- Keep away from flammable surface or items
- Do not obstruct casing Safety shut-off prevents overheating
- Do not touch metal case during operation, as it will be hot
- Unplug the mains lead before opening the housing
- A qualified technician should install and service this device
- Do not switch the device on immediately after it has been exposed to changes in temperature. Protect the device against damage by leaving it switched off until it has reached the room temperature.
- This device falls under protection Class I. It is therefore essential that the device be earthed.. Have a qualified person carry out the electronic connection.
- Make sure there is always enough liquid in the tank to keep the device from overheating. Unplug the device before filling the tank (do not overfill it) ! Close the screw cap firmly  
Remark: Do not operate the device when the tank is open
- Never use the machine when the liquid has overflowed the compartment
- Pour the fog liquid carefully to avoid the liquid overflow, which could result in electrical shock
- Smoke Machines are not designed for permanent operation: regular operation breaks will prolong their lives.
- Do not shake the device, Avoid brute force when installing or operating the device.
- Ensure the minimum distance of 1 meter between the device and any nearby surface or passer-by



- Use an appropriate safety cable to fix the device when mounting overhead
- Familiarize yourself with the functions of the device before actually using it
- All modifications of the device are forbidden for safety reasons
- The construction to which the device is attached should be able to support 10 times the weight of the device for one hour without deformation.
- Never stand directly below the device when it is being mounted, removed or serviced.
- Install the device in a location with few passers-by that is inaccessible to unauthorized persons

### Use:

- Place the machine horizontally and put the fog liquid carefully into the reservoir on the top of the fog machine
- After the warm-up time (approx. 5-8 minutes) the device is ready for use. The red indicator light at the wired Remote is now lit
- Wait until the indicator light on the wired remote lights up before pressing the button for fog
- Activate/deactivate the smoke output with the push button
- It may happen that the standby lamp on the controller is off and the smoke emission stops, even while you are holding the button. In this case the device is warming up again and will be ready to resume operation in a few minutes' time. This process guarantees an appropriate vaporization temperature and the best possible smoke emission.

### Cleaning and Maintenance:

1. All screws should be tightened and free of corrosion.
2. Mechanically moving parts must not show any signs of wear and tear.
3. The electric power supply cables must not show any damage. Have a qualified technician maintain the device.
4. Disconnect the device from the mains prior to maintenance activities.
5. Wipe the device regularly with a moist, lint-free cloth. Do not use alcohol or solvents.
6. There are no user-serviceable parts, apart from the fuse.
7. Clean the heating element after every 30 hours. Fill the tank with the cleaning liquid and let the machine run for a while. When the device is cleaned, remove the remaining cleaning liquid and rinse the tank thoroughly with distilled water. Never use regular water for cleaning or rinsing!

### Technical information:

- Voltage: 230Volt, 50/60Hz
- Input: 230VAC / 50HZ
- Fuse: 3A (replace fuse only with one of same type and size)
- Power: 400 WATT
- Tank capacity: 0,25 Liter
- Heat-up time: 2-5 minutes
- Fog Distance: 3-5 meters
- Smoke output: 70m<sup>3</sup> / min.
- Dimensions: 280 x 110 x 130 mm. (without Mounting Bracket)
- Weight: 1,85 Kg. (excl. liquid)

Manufacturer / Supplier will not be liable in the event that personal injury or consequential damage results from failure to observe these safety guidelines and the incorrect use of the device.



## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

## National contact

Denmark: 70 26 76 20  
[denmark@dancover.com](mailto:denmark@dancover.com)

UK: 020 8099 7570  
[uk@dancover.com](mailto:uk@dancover.com)

Germany: 041 0266 7040  
[germany@dancover.com](mailto:germany@dancover.com)

France: 0975 181 800  
[france@dancover.com](mailto:france@dancover.com)

Sweden: 040 233 262  
[sverige@dancover.com](mailto:sverige@dancover.com)

Finland: 0 931 581 720  
[suomi@dancover.com](mailto:suomi@dancover.com)

Poland: 22 300 8602  
[polska@dancover.com](mailto:polska@dancover.com)

Luxembourg: +49 041 0266 7040  
[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

Portugal: 308 800 899  
[portugal@dancover.com](mailto:portugal@dancover.com)

Spain: 911 436 828  
[espana@dancover.com](mailto:espana@dancover.com)

Italy: 02 479 21 198  
[italia@dancover.com](mailto:italia@dancover.com)

Switzerland: 0840 000125  
[schweiz@dancover.com](mailto:schweiz@dancover.com)

Austria: 0662 626935  
[austria@dancover.com](mailto:austria@dancover.com)

Norway: 231 00 690  
[norge@dancover.com](mailto:norge@dancover.com)

Nederland: 0 858 880 524  
[nederland@dancover.com](mailto:nederland@dancover.com)

Ireland: 0 151 33 003  
[ireland@dancover.com](mailto:ireland@dancover.com)

Belgium: 0 28 08 08 09  
[belgique@dancover.com](mailto:belgique@dancover.com)